

ZyXEL VES-1616F-44 3.50(ABI.6)C0

Release Note/Manual Supplement

Date: Jan. 16st, 2007

This document describes the features in the VES-1616F-44 product for its date code release.

Support Platforms:

ZyXEL VES-1616F-44 3.50(ABI.6)C0, supports models: ZyXEL VES-1616F-44

Version:

ZyNOS Version: V3.50(ABI.6)C0 | 01/16/2007 14:22:24

Bootbase Version: V1.02 | 01/08/2007 17:37:44

Default Bootbase Setting:

Please Note that the RomFile Checksum will be different for each device while generate SSH keys.

ZyNOS version : V3.50(ABI.6)C0 | 01/16/2007

bootbase version : V1.02 | 01/08/2007

Vendor Name : ZyXEL Communications Corp.

Product Model : VES-1616F-44

MAC Address : 00:19:cb:01:23:45

Default Country Code : ff

Boot Module Debug Flag : 1

RomFile Version : 0

RomFile Checksum : 5b8b

ZyNOS Checksum : 6d36

SNMP MIB level & OID : 61234567891011121314151617181920

Main Feature Bits : c0

Other Feature Bits :

f1 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
00 00 00 00 00 00 00 00 00 00 00 41 13 00 00 00

Bug Fix:

1. Reboot from field side of data abort is fixed.

Features:

Category	Type	Feature	Status
VDSL	Modem Code	Version	R105.38

Firmware Upgrade:

The VES-1616F-44 uses FTP to upgrade firmware in run-time through its built-in FTP server. You can use any FTP client (for example, [ftp.exe](#) in Windows) to upgrade VES-1616F-44. The upgrade procedure is as follows:

Upgrade VES-1616F-44 FW:

```
C:\> ftp <VES-1616F-44 IP address>
User : <Enter>
Password: 1234
230 Logged in
ftp> put 350ABI5D4.bin ras-0    (ras-1)
ftp> bye
```

Where

- User name : just press <Enter>
- Password : the management password, 1234 by default
- 350ABI5D4.bin : the name of firmware file you want to upgrade
- ras : the internal firmware name in VES-1616F-44

Configuration Upgrade:

The VES-1616F-44 uses FTP to upgrade configuration in run-time through its built-in FTP server. You can use any FTP client (for example, [ftp.exe](#) in Windows) to upgrade VES-1616F-44. The upgrade procedure is as follows:

Upgrade VES-1616F-44 configuration:

```
C:\> ftp <VES-1616F-44 IP address>
User : <Enter>
Password: 1234
230 Logged in
ftp> put 350ABI5D4.rom rom-0
ftp> bye
```

Where

- User name : just press <Enter>
- Password : the management password, 1234 by default
- 350ABI5D4.rom : the name of configuration file you want to upgrade
- rom-0 : the internal configuration name in VES-1616F-44

MIB support:

Please refer to “Known issues”.

Test Items:
