

## Upgrade Instructions

Note: Upgrading to firmware version 1.04.06 will cause you to lose your current configuration settings on your ZyAIR B-4000.

Before upgrading to firmware version 1.04.06, please check the current version on your ZyAIR B-4000.

If the current firmware version on your B-4000 is v1.02.01 or higher, you may proceed to upgrade to v1.04.06 either using the "Browse to PC" or "TFTP" in the embedded web configurator.

If the current firmware version on your B-4000 is v1.01.04 or lower, you must first upgrade to firmware version 1.02.01. After you have upgraded to v1.02.01, you may proceed to upgrade to v1.04.06 normally.

Thank you,  
ZyXEL Support