



Firmware Release Note

Prestige 334

Release 3.60(JJ.4)c0

Date:	December 21, 2004
Author:	Sandy Liu

ZyXEL Prestige 334 Standard Version release 3.60(JJ.4)c0 Release Note

Date: December 21, 2004

Supported Platforms:

ZyXEL Prestige 334

Versions:

ZyNOS F/W Version : VV3.60(JJ.4) | 12/21/2004 18:35:44
Bootbase Version: V1.02 | 03/22/2004 14:39:56

Notes:

1. This version supports quick route and enabled by default
2. The first entry of static route is reserved for system and read-only for users.

Known Issues:

1. The device fails to add a firewall ACL rule for NAT server set #12 automatically.
2. Allow NetBIOS traffic between WAN & LAN doesn't work when Firewall is enabled.
3. eWC/SMT: SUA/NAT->Address Mapping, the rules can be inserted more than 10 rules, and the rules will be invisible except first 10 rules.
4. If Prestige Router firmware version is later than V3.60(JJ.1), please **DO NOT** use eWC or FTP to upgrade V3.60(JJ.4) firmware. Instead, please use firmware upgrade tool (UpgradeTool_360JJ4c0.exe) to update V3.60(JJ.4) firmware. [See Appendix 1.](#)
5. If Prestige Router firmware version is later than V3.60(JJ.2), please do not FTP the downgrade firmware directly. Instead, follow these steps to downgrade:
Step 1: Change WAN IP assignment to Dynamic if it is set Static IP.
Step 2: Unplug WAN cable.
Step 3: Reboot device.
Step 4: Load the middle firmware (360JJ3c0-mid.bin) to device.
Step 5: Load the downgrade firmware to device.

CI Command List:

Features:

Modification in 3.60(JJ.4) | 12/21/2004

Convert version string from "3.60(JJ.4)b1" to "3.60(JJ.4)"

Modification in 3.60(JJ.4)b1 | 12/14/2004

1. [BUG FIX]
Symptom: Parental Control always disabled by license control.
Condition:
 1. Enable TMSS and Parental Control.
 2. Active your account on Dashboard of TMSS.
 3. Wait a period, Parental Control still disabled by license control. It should be enabled.
2. [BUG FIX]
Symptom: WAN traffic is slow when SUA Server port range is between 10000 and 30000.
Condition: In eWC-> SUA/NAT->SUA Server, set an inactive SUA server with start port 10000, end port 30000. While the SUA entry is there all out bound sessions are PATed to port 10000. And the browsing is slower, some pages don't load at all. When removing the entry, everything comes back to normal and all PATed sessions show different port.
3. [FEATURE ENHANCED]
Symptom: Chang Web page title to "ZyXEL Prestige 334 (hostname)" in login in page.

Modification in 3.60(JJ.3)C0 | 12/01/2004

Convert version string from "3.60(JJ.3)b5" to "3.60(JJ.3)"

TMSS Dashboard server (redirect) URL is

<http://tmss.trendmicro.com/dashboard/dashboard.aspx>

TMSS license URL is tmss.trendmicro.com/entitlement/tmssvalidateuser.aspx

TMSS active update server URL is

tmss-p.activeupdate.trendmicro.com/activeupdate/server.ini

Modification in 3.60(JJ.3)b5 | 11/15/2004

1. [BUG FIX]
Symptom: Apply call schedule rule to WAN ,DUT will crash
Condition:
 - 1.Set WAN encapsulation is PPPoE
 2. Edit a schedule rule name is 1
 - 3.Goto SMT Menu 11 , Set schedules=1 then save to rom
=>DUT will crash

Modification in 3.60(JJ.3)b4 | 11/01/2004

1. [BUG FIX]
Symptom: P2002 (P2P) SIP pass through test fail.
Condition: P2002 _1-----P-334 _1-----P-334 _2----- P2002 _2
 1. Phone call setting is P2P.

2. Set default server to P2002.
3. P2002_2 can't receive P2002_1's Ring.
2. [BUG FIX]
Symptom: Cannot access Dashboard correctly.
Condition: 1. Set you dashboard URL to beta.tmss.trendmicro.com.
2. Connect to "tmss.trendmicro.com/dashboard/" directly.
3. Browser will display message "you need a Trend Micro-approved router to connect to the Internet".

Modification in 3.60(JJ.3)b3 | 10/01/2004

1. [BUG FIX]
Symptom: P2002 (Proxy IP) SIP pass through test fail.
Condition: P2002_1-----P-334_1-----P-334_2----- P2002_2
1. Phone call setting is Proxy IP.
2. P2002_2 can't receive P2002_1's Ring.
2. [BUG FIX]
Symptom: P2002 (P2P) SIP pass through test fail.
Condition: P2002_1-----P-334_1-----P-334_2----- P2002_2
1. Phone call setting is P2P.
2. Set default server to P2002.
3. P2002_2 can't receive P2002_1's Ring.
3. [BUG FIX]
Symptom: AOL 9.0, Live video chat FAIL.
Condition: PC_1-----P-334_1-----P-334_2----- PC_2
1. "Live video chat" can't work.
4. [BUG FIX]
Symptom: Error log problem.
Condition: 1). In menu 24.8, "enter sys log err dis".
2). You will have the result below, by those dump we can see the serial number are not continuous. And the time was automatically add one hour (the actual time=display time - one hour).

```
1 Thu Sep 23 14:13:15 2004 PP10 WARN netMakeChannDial: err=-3001
rn_p=809de930
4 Thu Sep 23 14:13:18 2004 PP10 WARN netMakeChannDial: err=-3001
rn_p=809de930
8 Thu Sep 23 14:13:21 2004 PP10 WARN netMakeChannDial: err=-3001
rn_p=809de930
12 Thu Sep 23 14:13:24 2004 PP10 WARN netMakeChannDial: err=-3001
rn_p=809de930
14 Thu Sep 23 14:13:27 2004 PP10 WARN netMakeChannDial: err=-3001
rn_p=809de930
17 Thu Sep 23 14:13:30 2004 PP10 WARN netMakeChannDial: err=-3001
rn_p=809de930
18 Thu Sep 23 14:14:45 2004 PP1b WARN Last errorlog repeat 24 Times
20 Thu Sep 23 14:14:45 2004 PP10 WARN netMakeChannDial: err=-3001
```

ZyXEL Confidential

rn_p=809de930

21 Thu Sep 23 14:15:33 2004 PP15 WARN Last errorlog repeat 15 Times

5. [BUG FIX]

Symptom: DUT crash.

Condition: 1). Set WAN to PPTP mode.

2). Access support SSL's web site for a period of time and exception occurs.

EPC= 0x8009E5D0

SR= 0x00000003

CR= 0x9080840C

\$RA= 0x00000000

TLBS..\src\sys_isr.c:489 sysreset()

6. [FEATURE CHANGED]

Change the default AV Redirct URL to

"http://beta.tmss.trendmicro.com/dashboard/dashboard.asp", the default URL License Server to "beta.tmss.trendmicro.com/entitlement/tmssvalidateuser.aspx".

7. [BUG FIX]

Symptom: System Crash.

Condition: Using session.exe to generate lots of TCP port 80 sessions to P334 would cause device system reset.

8. [BUG FIX]

Symptom: Rom file damaged.

Condition: 1). eWC-> Firewall-> Services, add FTP(TCP:20,21) to Blocked Services, Apply.

2). eWC-> Firewall-> Services, delete FTP(TCP:20,21) from Blocked Services, Apply.

3). Reboot DUT, DUT will do crash dump cycle.

Modification in 3.60(JJ.3)b2 | 09/07/2004

1. [BUG FIX]

Symptom: System crash.

Condition: 1. Enable TMSS->Parental Control.

2. Connect to Internet and router would crash sometimes.

2. [FEATURE ENHANCED]

Router will trigger license check if client active register at dashboard.

3. [BUG FIX]

Symptom & Condition: Trend Micro Internet Security 2005 cannot display correctly at eWC.

4. [FEATURE CHANGED]

When enable/disable Trend Micro Security Services at Service Settings, router will also enable/disable Automatically update and parental control.

5. [BUG FIX]

Symptom & Condition: Html code is displayed on the Parental Control blocking page.

6. [BUG FIX]

ZyXEL Confidential

- Symptom: Display error in parental control.
Condition: 1. Active parental control.
2. After a period time.
3. In eWC->TMSS->Parental Control, has "0.0.0.0" displayed in address list.
7. [FEATURE CHANGED]
Change the default NAT UDP idle timeout from 180 to 300, the default NAT session per host from 2048 to 256.
8. [BUG FIX]
Symptom & Condition: Device will do rom convert after reset default rom.
9. [BUG FIX]
Symptom: ICMP packet cannot response.
Condition: 1. Enable Firewall and set default SUA server to a exist host.
2. ICMP packet would be blocked by Firewall.
10. [BUG FIX]
Symptom & Condition: Buttons of multi language cannot work when using Mozilla login.
11. [BUG FIX]
Symptom: & Condition: P334's picture not displays on Dashboard.
12. [BUG FIX]
Symptom: Display error in parental control.
Condition: 1. Active parental control.
2. After a period time.
3. In eWC->TMSS->Parental Control, has "0.0.0.0" displayed in address list.
13. [FEATURE CHANGED]
Change the redirect URL of TMSS from IP to domain name.
14. [FEATURE ENHANCED]
Support multi language for blocking page of Parental Control.
15. [BUG FIX]
Symptom: Can't save PPTP to static IP in Wizard configuration.
Condition: 1. In eWC-> Connection Wizard 2, change Encapsulation to PPTP.
2. In eWC-> Connection Wizard 3, select "Use fixed IP address" and set My WAN IP Address, Apply.
3. Screen display "Error: Subnet Mask format error."
16. [BUG FIX]
Symptom: Can't save any configuration in WAN ISP page.
Condition: 1. eWC-> ADVANCED->WAN-> WAN ISP, change any setting in this page and Apply.
2. Can't save & display "The range of NAT session number per user is from 1 to 2048".
17. [BUG FIX]
Symptom: Device crash while link to DHCP Table.
Condition: 1. Set LAN DHCP server to "None".
2. In eWC-> MAINTENANCE, click DHCP Table will cause device crash.

Modification in 3.60(JJ.3)b1 | 08/20/2004

ZyXEL Confidential

4. [FEATURE ENHANCED]
Support Trend Micro Security Services.
5. [FEATURE ENHANCED]
Modify F/W upgrade setup page to inform user using F/W upgrade tool to update F/W.

Modification in 3.60(JJ.2)D0 | 07/14/2004

18. [FEATURE CHANGED]
Convert from 3.60(JJ.2)C0 and change the default NAT UDP idle timeout from 300 to 180, the default NAT session per host from 256 to 2048.

Modification in 3.60(JJ.2)C0 | 07/07/2004

19. [FEATURE ENHANCED]
Convert to FCS version.

Modification in 3.60(JJ.2)b5 | 06/28/2004

1. [ENHANCEMENT]
Each unified ALG can be enabled/disabled. Default is enabled.
CI command:
 1. "ip alg display" to display the enable/disable information of each ALG.
 2. "ip alg enable
<ALG_FTP|ALG_MSMN|ALG_RA|ALG_ICQ|ALG_VoIP|ALG_SIP>" to enable an ALG.
 3. "ip alg disable
<ALG_FTP|ALG_MSMN|ALG_RA|ALG_ICQ|ALG_VoIP|ALG_SIP>" to disable an ALG.
2. [ENHANCEMENT]
Symptom: Support AOL Instant Messenger version 9.0
Condition:
 1. AOL 9.0 is NAT friendly, no need us to transfer for AOL.
 2. Add a CI-command "ip nat AOL-version9 <on/off>" to support AOL version 9.
AOL-version9: off. (Support under AOL version 8).
AOL-version9: on. (Support above AOL version 9).
The default value is AOL-version9: on.
3. [BUG FIXED]
Symptom: System crash.
Condition:
 1. Into eWC->ADVANCE->WAN->WAN ISP, set NAT to full feature.
 2. Into eWC->ADVANCE->SUA/NAT->Address Mapping, edit three one-to-one rule and one server rule.
 3. Delete the all NAT mapping rule, system crash.

Modification in 3.60(JJ.2)b4 | 06/18/2004

ZyXEL Confidential

6. [BUG FIXED]
Symptom: DNS server can't configuration.
Condition:
1). Restore default ROM file.
2). In eWC→ Wizard 3, Configure First DNS server type to user-defined then save.
3). In Menu 1, the First DNS server type still is From ISP.
7. [BUG FIXED]
In eWC→ Wizard 3, Wish change the word from Next to Finish on “Next” button.
8. [BUG FIXED]
1). Make sure WAN port is down & restore default rom.
2). In eWC→ Advance(System), Domain Name display zyxel.com.tw.
9. [BUG FIX]
Symptom: GUI wording.
Condition: 1). In eWC (French language)→ Advance (WAN)→ Route, Into
“Fournisseur WAN” page, you will see the word from “Fournisseur WAN” change to
“ISP WAN”.
10. [FEATURE ENHANCED]
Symptom: Use JavaScript to modify web page title as "ZyXEL [product name]
(hostname)".

Modification in 3.60(JJ.2)b3 | 06/15/2004

1. [BUG FIXED]
Symptom: content filter have some problem
Condition:
step1. In eWC->firewall->filter
step2. filter “ActiveX” or “ JAVA “
step3. Go to <http://java.sun.com/applets/other/UnderConstruction/index.html> test if
JAVA is blocked =>can not open JAVA test page but no display Denied Access
Message
2. [BUG FIXED]
Symptom: The packets on LAN (not to WAN) triggers the PPPoE connection.
Condition:
P334 connected to ADSL Modem, and 334 configured with pppoe encapsulation.
Ping LAN IP address (192.168.1.1) of 334 from a LAN-PC (192.168.1.33).
This packets will trigger 334 to dial PPPoE.
3. [FEATURE ENHANCED]
Add AT command “atld” to upload ROM file and write the ROM file to replace
default ROM file.
4. [BUG FIX]
Symptom & Condition: Telnet to menu 24.1, ” RAS F/W Version:n+ V3.60(JJ.2)b2 ”
should be ” ZyNOS F/W Version: V3.60(JJ.2)b2 ”
5. [BUG FIX]
Symptom & Condition: Telnet to menu 24.2.1, ”255” should be invisible.
6. [BUG FIX]
Symptom: DUT will be exception.

ZyXEL Confidential

Condition:

Step1. Route set NAT port forwarding address is PC address and disable firewall.

Step2. PC run application eMule for long time.

Modification in 3.60(JJ.2)b2 | 05/26/2004

1. [BUG FIXED]
Symptom: DUT will be exception.
Condition:
step1. WAN port connect to IPTV server
step2. Enable LAN/WAN IGMP v1 , Disable firewall
step3. Run IPTV viewer on LAN site PC => DUT exception.
2. [BUG FIXED]
Symptom: DUT will be exception.
Condition:
Step1. Set all(10) address mapping rule with many to one to one
Step2. Delete all(10) address mapping rule
Step3. Repeat step1-step2 more time DUT will be exception
3. [BUG FIXED]
Symptom: DHCP configure have some problem
Condition: In SMT Menu 3.2, Set IP starting address is not same LAN IP segment and press enter to save config => No display error message and it still can save
4. [BUG FIXED]
Symptom: LAN IP alias setup problem
Condition :
step1. In SMT Menu 3.2.1 setup IP alias
step2. setup IP alias1 is 192.168.2.1 submask is 255.255.255.255 and press enter to save
5. [BUG FIXED]
Symptom :VPN NAT-Traversal have some problem
Condition : PC1---ZW5----NAT----P334----PC2
When VPN rule NAT-Traversal ON , Local ID and Peer ID with domain name or Email
VPN tunnel can not establish . Same VPN rule , Local ID and Peer ID with IP , VPN tunnel can establish.
6. [BUG FIXED]
Symptom: eWC: SUA/NAT->Address Mapping, the rules can be inserted more than 10 rules, and the rules will be invisible expect first 10 rules.
Condition: eWC: SUA/NAT->Address Mapping, to insert more than 10 rules.

Modification in 3.60(JJ.2)b1 | 05/12/2004

1. [FEATURE ENHANCED]
Sync code from trunk at 03/18/2004.
2. [FEATURE CHANGED]
Remove the Online Help.

ZyXEL Confidential

3. [FEATURE ENHANCED]
Support SIP pass through.
4. [FEATURE ENHANCED]
Support PPTP with dynamic IP.
5. [FEATURE ENHANCED]
Support Multi lingual
6. [FEATURE CHANGED]
Change default setting of quick route, disable quick route when firewall enable.

Modification in 3.60(JJ.1)b2 | 3/24/2004

1. [FEATURE CHANGED]
Turn on Firewall and turn off UPNP by default.

Modification in 3.60(JJ.0)b9 | 1/13/2004

1. [BUG FIXED]
Symptom: Exception occurs during boot procedure after restore default rom file by CI command.

Modification in 3.60(JJ.0)b8 | 1/9/2004

1. [BUG FIXED]
Symptom: Content filter cannot block cookie content for some web sites.
Condition: 1. Enable "block cookie" in eWC. 2. Access
<http://www.tomshardware.com> from PC. 3. PC has cookie contents which are written from the website. Router should block the cookie contents.
2. [BUG FIXED]
Symptom: Exception occurs when connect with PQA Reback PPPoE Server.

Modification in 3.60(JJ.0)b7 | 12/31/2003

1. [BUG FIXED]
Symptom: Exception occurs when configure WAN interface as PPPoE in eWC.
2. [BUG FIXED]
Symptom: Logged into the eWC from one computer and then try to login from a second one. The login fails, but the centralize log states that the login was successful.
3. [FEATURE ENHANCED]
Change the warning message of Daylight saving from "Start date cannot greater than end date" to "Start Date must occur before End Date."
4. [FEATURE ENHANCED]

ZyXEL Confidential

eWC online help is updated for Remote Management ->Security.

Modification in 3.60(JJ.0)b6 | 12/11/2003

1. [BUG FIXED]
Symptom: Exception occurs when DNS server replies a request for more then once.

Modification in 3.60(JJ.0)b5 | 12/09/2003

1. [BUG FIXED]
Symptom: Avoid ipsec_list linking list be destroyed by chk_conn.
2. [BUG FIXED]
Symptom: Help page <http://192.168.1.1/RestoreErr.html#> is not available.
3. [BUG FIXED]
Symptom: 1."WIZARD 2" -> select PPTP and finish editing(My IP Subnet Mask = 255.0.0.0) 2."WIZARD 3"-> the "IP Subnet Mask" always be "255.0.0.0".
4. [BUG FIXED]
Symptom: Relogin Period (min) default setting is 0 min for Telia Login, but it show "30 min" in help page.
5. [BUG FIXED]
Symptom: System crash when user access a long URL web site.
Condition: 1. Enable content filter. 2. Set the current time within range of content filter's blocking time. 3. Open a web browser and access a web site whose URL is very long. 4. System will crash.
6. [BUG FIXED]
Symptom: cbuf double free caused by DNS query.
7. [FEATURE CHANGED]
Symptom: Default setting for allowing Netbios traffic is changed to "Disable".

Modification in 3.60(JJ.0)b4 | 11/13/2003

1. [BUG FIXED]
Symptom: Issue CI command "sys romr" can not restore default rom file via Telnet.
Condition: (1) Issue "sys romr" in menu 24.8 via Telnet. (2) It does not send out the message "Do you want to restore default ROM file(y/n)?".
2. [BUG FIXED]
Symptom: Into eWC--> Wizard, Can't save Gateway IP Address if you configure WAN = Ethernet and fixed IP.

ZyXEL Confidential

3. [BUG FIXED]
Symptom: Upnp function "Allow users to make configuration changes through UPnP" can't work correctly.
4. [BUG FIXED]
Symptom: Output first 3 characters of username and password of Telia login.
5. [BUG FIXED]
Symptom: The menu "Static Route" is not accessible with Linux Mozilla Firebird.
6. [BUG FIXED]
Symptom: GUI problem for Telia Login setting.
Condition: (1)Into eWC--> WAN--> WAN ISP, Setting Telia Login and Relogin Every(min) = 10 then save it. (2)Into eWC--> Wizard 2, you will see the value of "Relogin Every(min)" is not 10.
7. [FEATURE CHANGED]
Quick route is disabled when there exist IPSec tunnels.

Modification in 3.60(JJ.0)b3 | 11/05/2003

1. [BUG FIXED]
Symptom: Windows 2000 command line FTP client cannot get file from FTP server in WAN side.
2. [BUG FIXED]
Symptom: The modification in lower part of eWC content filter page cannot be saved after apply the change of upper part settings.
3. [BUG FIXED]
Symptom: PPPoE idletime value will be change to "0" when you Enable traffic redirect function from eWC.
4. [BUG FIXED]
Symptom: There is no help in GUI for Telia login.
5. [BUG FIXED]
Symptom: After running VPN FTP stress test several hours, LeapFTP can't login to Serv-U of remote's PC again. (It can work if you disable quick route)
6. [BUG FIXED]
Symptom: Run NAT function auto test, P334 will crash.
7. [BUG FIXED]
Symptom: Time Protocol & Time server address default settings are different from help page <http://192.168.1.1/TimeZone.html#>.

Modification in 3.60(JJ.0)b2 | 10/21/2003

1. [BUG FIXED]
Symptom: Press "Apply" on WebGUI "WAN ISP" page will get an error message: "ERROR: Fail to update due to internal error (-9)!" and the outgoing traffic from WAN port is blocked.
Condition: 1: Configure PPPoE with fixed IP address in eWC . 2: Change the encapsulation from PPPoE to Ethernet. 3: Choose RR-Toshiba/RR-Manager/RR-Telstra/RR-Telia as the Service Type. 4: Click "Apply" The status shows: "ERROR: Fail to update due to internal error (-9)!" and the outgoing traffic from WAN port is blocked.
2. [BUG FIXED]
Symptom: Configure traffic redirect all fields via eWC that cause P334 crash.
3. [BUG FIXED]
Symptom: Enter eWC--> Firewall--> Services, select " any(UDP)" rule then click add button that cause P334 crash.
4. [BUG FIXED]
Symptom: Exception occurs when VPN tunnel is activated but PPPoE/PPTP connection is not established yet.
Condition: 1. Set WAN Encapsulation = PPPoE. 2. Create one VPN rule and activate it. The exception occurs in 10 seconds.
5. [BUG FIXED]
Symptom: Change Encryption Algorithm from DES to " 3DES " while transfer file that will cause P334 crash.
Condition: 1. Create one VPN rule and connect with ZW2. 2. Remote PC Transfer file to Local via VPN tunnel. 3. Into ZW2 menu27.1.1.1, change Encryption Algorithm from DES to " 3DES " in IKE phase1 and save it.
6. [BUG FIXED]
Symptom: The location of private field is incorrect.
Condition: 1. Set WAN= PPPoE or PPTP, and go to menu 11.3. 2. The cursor is located on wrong position for " Private " & "RIP Direction".
7. [BUG FIXED]
Symptom: Cannot Access P334 after change network on WAN.
Condition: 1. Set WAN= Ethernet/ Static IP via eWC, and connect the WAN port with PQA internal LAN. 2. Connect WAN port to ZyXEL's internal LAN 3. Modify WAN= Ethernet/ Dynamic via eWC. 4. P334 cannot be accessed anymore.
8. [BUG FIXED]
Symptom: In Wizard last page " <http://192.168.1.1/wzError.html#> " that Help is not

ZyXEL Confidential

available. (網頁發生錯誤)

9. [FEATURE ENHANCED]
Change the default page of remote management in eWC to “WWW”.
10. [BUG FIXED]
In eWC--> WAN--> Route, remove all wording for dial backup in http://192.168.1.1/WAN_Route.html# help page.
11. [BUG FIXED]
Correct all “ZyWALL” terms in help pages of IPSec VPN.
12. [BUG FIXED]
Correct the typo “Remode Management” to “Remote Management” in Remote management help pages.
13. [FEATURE CHANGED]
Support Telia login.

Modification in 3.60(JJ.0)b1 | 09/30/2003


1. First firmware release

Appendix 1: ZyXEL F/W Upgrade Tool

Network Environment:

1. Prestige Router Series

The target network environment is a small number of PCs using the Prestige DHCP service for IP address assignment. Following figure shows a typical Internet access application.



Firmware Upgrade Procedure

1. Change the Router's password to “1234”.
2. Change the Router's LAN IP to “192.168.1.1” and make sure that PC can connect to Router.
 - ⇒ If your PC's IP is dynamic assigned by router, please release original IP and

renew it from router's DHCP service.

⇒ If your PC's IP is static assigned, please change it and make sure the new IP address at same subnet with router. (Ex: Set PC's IP to 192.168.1.33).

3. Logout the Router.
 4. Executing the upgrade tool and wait about 6 minutes to wait firmware upgrade procedure finished.
- ◆ Trouble shooting
1. Make sure the password is correct.
 2. If upgrade fail, unplug WAN cable and reboot the device and then try again.
 3. Make sure the setting for Telnet port as 23 and FTP port as 21.

Annex A CI Command List

Last Updated: 2002/11/26

Command Class List Table		
System Related Command	Exit Command	Device Related Command
Ethernet Related Command	POE Related Command	PPTP Related Command
Configuration Related Command	IP Related Command	IPSec Related Command
Firewall Related Command		

System Related Command

[Home](#)

Command			Description
sys			
	adptime		retrive date and time from Internet
	callhist		
	display		display call history
	remove	<index>	remove entry from call history
	countrycode	[countrycode]	set country code
	date	[year month date]	set/display date
	domainname		display domain name
	edit	<filename>	edit a text file
	extraphnum		maintain extra phone numbers for outcalls
	add	<set 1-3> <1 st phone num> [2 nd phone num]	add extra phone numbers
	display		display extra phone numbers
	node	<num>	set all extend phone number to remote node <num>
	remove	<set 1-3>	remove extra phone numbers
	reset		reset flag and mask
	feature		display feature bit
	hostname	[hostname]	display system hostname
	logs		
	category		
		access [0:none/1:log/2:alert/3:both]	record the access control logs
		attack [0:none/1:log/2:alert/3:both]	record and alert the firewall attack logs
		display	display the category setting
		error [0:none/1:log/2:alert/3:both]	record and alert the system error logs
		ipsec [0:none/1:log/2:alert/3:both]	record the access control logs
		ike [0:none/1:log/2:alert/3:both]	record the access control logs
		javablocked [0:none/1:log]	record the java etc. blocked logs
		mten [0:none/1:log]	record the system maintenance logs
		upnp [0:none/1:log]	record upnp logs
		urlblocked [0:none/1:log/2:alert/3:both]	record and alert the web blocked logs
		urlforward [0:none/1:log]	record web forward logs
	clear		clear log
	display	[access attack error ipsec ike javablocked mten urlblocked urlforward]	display all logs or specify category logs
	errlog		
		clear	display log error
		disp	clear log error
		online	turn on/off error log online display
	load		load the log setting buffer
	mail		
		alertAddr [mail address]	send alerts to this mail address

ZyXEL Confidential

			display	display mail setting
			logAddr [mail address]	send logs to this mail address
			schedule display	display mail schedule
			schedule hour [0-23]	hour time to send the logs
			schedule minute [0-59]	minute time to send the logs
			schedule policy [0:full/1:hourly/2:daily/3:weekly/4:none]	mail schedule policy
			schedule week [0:sun/1:mon/2:tue/3:wed/4:thu/5:fri/6:sat]	weekly time to send the logs
			server [domainName/IP]	mail server to send the logs
			subject [mail subject]	mail subject
		save		save the log setting buffer
		syslog		
			active [0:no/1:yes]	active to enable unix syslog
			display	display syslog setting
			facility [Local ID(1-7)]	log the messages to different files
			server [domainName/IP]	syslog server to send the logs
	log			
		clear		clear log error
		disp		display log error
		online	[on/off]	turn on/off error log online display
		resolve		Resolve mail server and syslog server address
	mbuf			
		link	link	list system mbuf link
		pool	<id> [type]	list system mbuf pool
		status		display system mbuf status
		disp	<address>	display mbuf status
		cnt		
			disp	display system mbuf count
			clear	clear system mbuf count
		debug	[on/off]	
	pwderrtm		[minute]	Set or display the password error blocking timeout value.
	rn			
		load	<entry no.>	load remote node information
		disp	<entry no.>(0:working buffer)	display remote node information
		nat	<none/sua/full feature>	config remote node nat
		nailup	<no/yes>	config remote node nailup
		mtu	<value>	set remote node mtu
		save	[entry no.]	save remote node information
	smt			not support in this product
	stdio		[minute]	change terminal timeout value
	time		[hour [min [sec]]]	display/set system time
	treisp			monitor packets
	trelog			
	trepacket			
	syslog			
		server	[destIP]	set syslog server IP address
		facility	<FacilityNo>	set syslog facility
		type	[type]	set/display syslog type flag
		mode	[on/off]	set syslog mode
	version			display RAS code and driver version

ZyXEL Confidential

	view		<filename>	view a text file
	wdog			
		switch	[on/off]	set on/off wdog
		cnt	[value]	display watchdog counts value: 0-34463
	romreset			restore default romfile
	server			
		access	<telnet ftp web icmp snmp dns> <value>	set server access type
		load		load server information
		disp		display server information
		port	<telnet ftp web snmp> <port>	set server port
		save		save server information
		secureip	<telnet ftp web icmp snmp dns> <ip>	set server secure ip addr
	fwnotify			
		load		load fwnotify entry from spt
		save		save fwnotify entry to spt
		url	<url>	set fwnotify url
		days	<days>	set fwnotify days
		active	<flag>	turn on/off fwnotify flag
		disp		display firmware notify information
		check		check firmware notify event
		debug	<flag>	turn on/off firmware notify debug flag
	cmgr			
		trace		
			disp <ch-name>	show the connection trace of this channel
			clear <ch-name>	clear the connection trace of this channel
		cnt	<ch-name>	show channel connection related counter
	socket			display system socket information
	filter			
		netbios		
	roadrunner			
		debug	<level>	enable/disable roadrunner service 0: disable <default> 1: enable
		display	<iface name>	display roadrunner information iface-name: enif0, wanif0
		restart	<iface name>	restart roadrunner
	ddns			
		debug	<level>	enable/disable ddns service
		display	<iface name>	display ddns information
		restart	<iface name>	restart ddns
		logout	<iface name>	logout ddns
	cpu			
		display		display CPU utilization
	filter			
		netbios		
	upnp			
		active	[0:no/1:yes]	Activate or deactivate the saved upnp settings
		config	[0.deny/1.permit]	Allow users to make configuration changes. through UPnP
		display		display upnp information
		firewall	[0.deny/1.pass]	Allow UPnP to pass through Firewall.
		load		save upnp information
		save		save upnp information

Exit Command

[Home](#)

Command				Description
exit				exit smt menu

Device Related Command

[Home](#)

Command				Description
dev				
	channel			
		drop	<channel name>	drop channel
	dial		<node#>	dial to remote node

Ethernet Related Command

[Home](#)

Command				Description
ether				
	config			display LAN configuration information
	driver			
		cnt		
			disp <name>	display ether driver counters
		ioctl	<ch_name>	Useless in this stage.
		status	<ch_name>	see LAN status
	version			see ethernet device type
	pkttest			
		disp		
			packet <level>	set ether test packet display level
			event <ch> [on/off]	turn on/off ether test event display
		sap	[ch_name]	send sap packet
		arp	<ch_name> <ip-addr>	send arp packet to ip-addr
	debug			
		disp	<ch_name>	display ethernet debug information
		level	<ch_name> <level>	set the ethernet debug level level 0: disable debug log level 1:enable debug log (default)
	edit			
		load	<ether no.>	load ether data from spt
		mtu	<value>	set ether data mtu
		accessblock	<0:disable 1:enable>	block internet access
		save		save ether data to spt

POE Related Command

[Home](#)

Command				Description
poe				
	status		[ch_name]	see poe status
	dial		<node>	dial a remote node
	drop		<node>	drop a pppoe call
	ether		[rfc3com]	set /display pppoe ether type

PPTP Related Command

[Home](#)

Command				Description
pptp				
	dial		<rn-name>	dial a remote node
	drop		<rn-name>	drop a remote node call
	tunnel		<tunnel id>	display pptp tunnel information

Configuration Related Command

[Home](#)

Command					Description
config					The parameters of config are listed below.
edit	firewall	active <yes no>			Activate or deactivate the saved firewall settings
retrieve	firewall				Retrieve current saved firewall settings
save	firewall				Save the current firewall settings
display	firewall				Displays all the firewall settings
		set <set#>			Display current entries of a set configuration; including timeout values, name, default-permit, and number of rules in the set.
		set <set#>	rule <rule#>		Display current entries of a rule in a set.
		attack			Display all the attack alert settings in PNC
		e-mail			Display all the e-mail settings in PNC
		?			Display all the available sub commands
		e-mail	mail-server <mail server IP>		Edit the mail server IP to send the alert
			return-addr <e-mail address>		Edit the mail address for returning an email alert
			e-mail-to <e-mail address>		Edit the mail address to send the alert
			policy <full hourly daily weekly>		Edit email schedule when log is full or per hour, day, week.
			day <sunday monday tuesday wednesday thursday friday saturday>		Edit the day to send the log when the email policy is set to Weekly
			hour <0~23>		Edit the hour to send the log when the email policy is set to daily or weekly
			minute <0~59>		Edit the minute to send to log when the email policy is set to daily or weekly
			Subject <mail subject>		Edit the email subject
		attack	send-alert <yes no>		Activate or deactivate the firewall DoS attacks notification emails
			block <yes no>		Yes: Block the traffic when exceeds the tcp-max-incomplete threshold
					No: Delete the oldest half-open session when exceeds the tcp-max-incomplete threshold
			block-minute <0~255>		Only valid when sets 'Block' to yes. The unit is minute
			minute-high <0~255>		The threshold to start to delete the old half-opened sessions to minute-low
			minute-low <0~255>		The threshold to stop deleting the old half-opened session
			max-incomplete-high <0~255>		The threshold to start to delete the old half-opened sessions to max-incomplete-low
			max-incomplete-low <0~255>		The threshold to stop deleting the half-opened session
			tcp-max-incomplete <0~255>		The threshold to start executing the block field
		set <set#>	name <desired		Edit the name for a set

ZyXEL Confidential

			name>		
			default-permit <forward block>		Edit whether a packet is dropped or allowed when it does not match the default set
			icmp-timeout <seconds>		Edit the timeout for an idle ICMP session before it is terminated
			udp-idle-timeout <seconds>		Edit the timeout for an idle UDP session before it is terminated
			connection-timeout <seconds>		Edit the wait time for the SYN TCP sessions before it is terminated
			fin-wait-timeout <seconds>		Edit the wait time for FIN in concluding a TCP session before it is terminated
			tcp-idle-timeout <seconds>		Edit the timeout for an idle TCP session before it is terminated
			pnc <yes no>		PNC is allowed when 'yes' is set even there is a rule to block PNC
			log <yes no>		Switch on/off sending the log for matching the default permit
			rule <rule#>	permit <forward block>	Edit whether a packet is dropped or allowed when it matches this rule
				active <yes no>	Edit whether a rule is enabled or not
				protocol <0~255>	Edit the protocol number for a rule. 1=ICMP, 6=TCP, 17=UDP...
				log <none match not-match both>	Sending a log for a rule when the packet none matches not match both the rule
				alert <yes no>	Activate or deactivate the notification when a DoS attack occurs or there is a violation of any alert settings. In case of such instances, the function will send an email to the SMTP destination address and log an alert.
				srcaddr-single <ip address>	Select and edit a source address of a packet which complies to this rule
				srcaddr-subnet <ip address> <subnet mask>	Select and edit a source address and subnet mask if a packet which complies to this rule.
				srcaddr-range <start ip address> <end ip address>	Select and edit a source address range of a packet which complies to this rule.
				destaddr-single <ip address>	Select and edit a destination address of a packet which complies to this rule
				destaddr-subnet <ip address> <subnet mask>	Select and edit a destination address and subnet mask if a packet which complies to this rule.
				destaddr-range <start ip address> <end ip address>	Select and edit a destination address range of a packet which complies to this rule.
				tcp destport-single <port#>	Select and edit the destination port of a packet which comply to this rule. For non-consecutive port numbers, the user may repeat this command line to enter the multiple port numbers.
				tcp destport-range <start port#> <end port#>	Select and edit a destination port range of a packet which comply to this rule.
				udp destport-single <port#>	Select and edit the destination port of a packet which comply to this rule. For non-consecutive port numbers, users may repeat this command line to enter the multiple port numbers.
				udp destport-range <start port#> <end port#>	Select and edit a destination port range of a packet which comply to this rule.
				desport-custom <desired	Type in the desired custom port name

ZyXEL Confidential

				custom port name>	
delete	firewall	e-mail			Remove all email alert settings
		attack			Reset all alert settings to defaults
		set <set#>			Remove a specified set from the firewall configuration
		set <set#>	rule <rule#>		Remove a specified rule in a set from the firewall configuration
insert	firewall	e-mail			Insert email alert settings
		attack			Insert attack alert settings
		set <set#>			Insert a specified rule set to the firewall configuration
		set <set#>	rule <rule#>		Insert a specified rule in a set to the firewall configuration
cli					Display the choices of command list.
debug	<1 0>				Turn on off trace for firewall debug information.

IP Related Command

[Home](#)

Command				Description
ip				
	address		[addr]	display host ip address
	alias		<iface>	alias iface
	aliasdis		<0 1>	disable alias
	arp			
		status	<iface>	display ip arp status
	dhcp		<iface>	
		client		
			release	release DHCP client IP
			renew	renew DHCP client IP
		status	[option]	show dhcp status
	dns			
		query		
		server	<primary> [secondary] [third]	set dns server
		stats		
			clear	clear dns statistics
			disp	display dns statistics
	httpd			
	icmp			
		status		display icmp statistic counter
		discovery	<iface> [on off]	set icmp router discovery flag
	ifconfig		[iface] [ipaddr] [broadcast <addr> [mtu <value> dynamic]	configure network interface
	ping		<hostid>	ping remote host
	route			
		status	[if]	display routing table
		add	<dest_addr default>[/<bits>] <gateway> [<metric>]	add route
		addiface	<dest_addr default>[/<bits>] <gateway> [<metric>]	add an entry to the routing table to iface
		addprivate	<dest_addr default>[/<bits>] <gateway> [<metric>]	add private route
		drop	<host addr> [/<bits>]	drop a route
	smtp			
	status			display ip statistic counters
	stroute			

ZyXEL Confidential

		display	[rule # buf]	display rule index or detail message in rule.
		load	<rule #>	load static route rule in buffer
		save		save rule from buffer to spt.
		config		
			name <site name>	set name for static route.
			destination <dest addr>[/<bits>] <gateway> [<metric>]	set static route destination address and gateway.
			mask <IP subnet mask>	set static route subnet mask.
			gateway <IP address>	set static route gateway address.
			metric <metric #>	set static route metric number.
			private <yes/no>	set private mode.
			active <yes/no>	set static route rule enable or disable.
	traceroute		<host> [ttl] [wait] [queries]	send probes to trace route of a remote host
	xparent			
		join	<iface1> [<iface2>]	join iface2 to iface1 group
		break	<iface>	break iface to leave ipxparent group
	urlfilter			
		reginfo		
			display	display urlfilter registration information
			name	set urlfilter registration name
			eMail <size>	set urlfilter registration email addr
			country <size>	set urlfilter registration country
			clearAll	clear urlfilter register information
		category		
			display	display urlfilter category
			webFeature [block/nonblock] [activex/java/cookei/webproxy]	block or unblock webfeature
			logAndBlock [log/logAndBlock]	set log only or log and block
			blockCategory [block/nonblock] [all/type(1-14)]	block or unblock type
			timeOfDay [always/hh:mm] [hh:mm]	set block time
			clearAll	clear all category information
		listUpdate		
			display	display listupdate status
			actionFlags [yes/no]	set listupdate or not
			scheduleFlag [pending]	set schedule flag
			dayFlag [pending]	set day flag
			time [pending]	set time
			clearAll	clear all listupdate information
		exemptZone		
			display	display exemptzone information
			actionFlags [type(1-3)][enable/disable]	set action flags
			add [ip1] [ip2]	add exempt range
			delete [ip1] [ip2]	delete exempt range
			clearAll	clear exemptzone information
		customize		
			display	display customize action flags
			actionFlags[filterList/disableAllExce ptTrusted/unblockRWFToTrusted/k eywordBlock/fullPath/caseInsensi ve/fileName][enable/disable]	set action flags
			logFlags [type(1-3)][enable/disable]	set log flags
			add [string] [trust/untrust/keyword]	add url string

ZyXEL Confidential

			delete [string] [trust/untrust/keyword]	delete url string
			clearAll	clear all information
		logDisplay		display cyber log
		ftplist		update cyber list data
		listServerIP	<ipaddr>	set list server ip
		listServerName	<name>	set list server name
	tredir			
		failcount	<count>	set tredir failcount
		partner	<ipaddr>	set tredir partner
		target	<ipaddr>	set tredir target
		timeout	<timeout>	set tredir timeout
		checktime	<period>	set tredir checktime
		active	<on/off>	set tredir active
		save		save tredir information
		disp		display tredir information
		debug	<value>	set tredir debug value
	nat			
		hashTable	<enifX>; X=0, 1, 2....	display nat hash table
		server		
			disp	display nat server table
			load <set id>	load nat server information from ROM
			save	save nat server information to ROM
			clear <set id>	clear nat server information
			edit active <yes no>	set nat server edit active flag
			edit svrport <start port> [end port]	set nat server server port
			edit intport <start port> [end port]	set nat server forward port
			edit remotehost <start ip> [end ip]	set nat server remote host ip
			edit leasetime [time]	set nat server lease time
			edit rulename [name]	set nat server rule name
			edit forwardip [ip]	set nat server server ip
			edit protocol [protocol id]	set nat server protocol
			edit clear	clear one rule in the set
		service		
			irc [on/off]	turn on/off irc flag
		resetport		reset all nat server table entries
		incikeport	[on/off]	turn on/off increase ike port flag
		session		set NAT session per host
		AOL-vision9	<on/off>	support AOL version 9 or not
	enforcer	active	<on/off>	set TMSS enable or disable
		av		
			active <on/off>	Enable or disable Automatically check for update components
			checktime	Set the checking time
			server	Set the server's URL
			versio	Display Engine Version and Pattern number
			disp	Display current active server IP address
			refresh	Refresh active server
		redirect url		Set redirect URL
		time		
			report	Set report time
			outdate	Set time out
			update	Set update time
		display		Display TMSS setting
		get	<server_addr><port><filename>	Get server.ini

		except		
			add	Add client to exception list
			del	Delete client from exception list
			display	Display exception list
		discover	<ipAddr>	Update client information
		notify	<ipAddr>	Notify client update engine/pattern
		client		
			init	Initial client pool
			display	Display client pool
			get	Display client information
			del	Delete client from client pool
			reset	Reset client pool
			add	Add client to client pool
		debug	[1:ERROR 2:DEBUG 4:INFO 8:WARN 16:CRIT 32:NOTICE 63:ALL]	Print debug message
		url		
			Active	Enable/disable parental control
			server	Set License server URL
			category	Set parental control category
			display	Display Parental control setting
			reset	Reset Parental control statistics
		queue		Display the pending queue
	igmp			
		debug	[level]	set igmp debug level
		forwardall	[on/off]	turn on/off igmp forward to all interfaces flag
		querier	[on/off]	turn on/off igmp stop query flag
		iface		
			<iface> grouptm <timeout>	set igmp group timeout
			<iface> interval <interval>	set igmp query interval
			<iface> join <group>	join a group on iface
			<iface> leave <group>	leave a group on iface
			<iface> query	send query on iface
			<iface> rsptime [time]	set igmp response time
			<iface> start	turn on of igmp on iface
			<iface> stop	turn off of igmp on iface
			<iface> ttl <threshold>	set ttl threshold
			<iface> v1compat [on/off]	turn on/off v1compat on iface
		robustness	<num>	set igmp robustness variable
		status		dump igmp status
	alg			
		display		Display the enable/disable information of each ALG
		enable	<ALG_FTP ALG_MSMN ALG_RA ALG_ICQ ALG_VoIP ALG_SIP>	Enable an ALG
		disable	<ALG_FTP ALG_MSMN ALG_RA ALG_ICQ ALG_VoIP ALG_SIP>	Disable an ALG

IPSec Related Command

[Home](#)

Command				Description
ipsec				
	debug	<1 0>		turn on/off trace for IPsec debug information
	ipsec log disp			show IPSec log, same as menu 27.3
	route	lan	<on off>	After a packet is IPSec processed and will be

ZyXEL Confidential

				sent to LAN side, this switch is to control if this packet can be applied IPSec again.
				Remark: Command available since 3.50(WA.3)
		wan	<on off>	After a packet is IPSec processed and will be sent to WAN side, this switch is to control if this packet can be applied IPSec again.
				Remark: Command available since 3.50(WA.3)
	show_runtime	sa		display runtime phase 1 and phase 2 SA information
		spd		When a dynamic rule accepts a request and a tunnel is established, a runtime SPD is created according to peer local IP address. This command is to show these runtime SPD.
	switch	<on off>		As long as there exists one active IPSec rule, all packets will run into IPSec process to check SPD. This switch is to control if a packet should do this. If it is turned on, even there exists active IPSec rules, packets will not run IPSec process.
	timer	chk_my_ip	<1~3600>	- Adjust timer to check if WAN IP in menu is changed
				- Interval is in seconds
				- Default is 10 seconds
				- 0 is not a valid value
		chk_conn.	<0~255>	- Adjust auto-timer to check if any IPsec connection has no traffic for certain period. If yes, system will disconnect it.
				- Interval is in minutes
				- Default is 2 minutes
				- 0 means never timeout
		update_peer	<0~255>	- Adjust auto-timer to update IPSec rules which use domain name as the secure gateway IP.
				- Interval is in minutes
				- Default is 30 minutes
				- 0 means never update
				Remark: Command available since 3.50(WA.3)
	updatePeerIp			Force system to update IPSec rules which use domain name as the secure gateway IP right away.
				Remark: Command available since 3.50(WA.3)
	dial	<rule #>		Initiate IPSec rule <#> from ZyWALL box
				Remark: Command available since 3.50(WA.3)
	display	<rule #>		Display IPSec rule #
	remote	key	<string>	I add a secured remote access tunnel with pre-shared key. It is a dynamic rule with local: the route's WAN IP. The algorithms with it are fixed to phase1: DES+MD5, DH1 and SA lifetime 28800 seconds; phase2: DES+MD5, PFS off, no anti-replay and SA lifetime 28800 seconds. The length of pre-shared key is between 8 to 31 ASCII characters.
		switch	<on off>	Activate or de-activate the secured remote access tunnel.
	keep_alive	<rule #>	<on off>	Set ipsec keep_alive flag
	load	<rule #>		Load ipsec rule
	save			Save ipsec rules

ZyXEL Confidential

	config	netbios	active <on off>	Set netbios active flag
			group <group index1, group index2...>	Set netbios group
		name	<string>	Set rule name
		name	<string>	Set rule name
		keepAlive	<Yes No>	Set keep alive or not
		localIdType	<0:IP 1:DNS 2:Email>	Set local ID type
		localIdContent	<string>	Set local ID content
		myIpAddress	<IP address>	Set my IP address
		peerIdType	<0:IP 1:DNS 2:Email>	Set peer ID type
		peerIdContent	<string>	Set peer ID content
		secureGwAddr	<IP address Domain name>	Set secure gateway address or domain name
		protocol	<1:ICMP 6:TCP 17:UDP>	Set protocol
		localAddrType	<0:single 1:range 2:subnet>	Set local address type
		localAddrStart	<IP>	Set local start address
		localAddrEndMask	<IP>	Set local end address or mask
		localPortStart	<port>	Set local start port
		localPortEnd	<port>	Set local end port
		remoteAddrType	<0:single 1:range 2:subnet>	Set remote address type
		remoteAddrStart	<IP>	Set remote start address
		remoteAddrEndMask	<IP>	Set remote end address or mask
		remotePortStart	<port>	Set remote start port
		remotePortEnd	<port>	Set remote end port
		antiReplay	<Yes No>	Set antireplay or not
		keyManage	<0:IKE 1:Manual>	Set key manage
		ike	negotiationMode <0:Main 1:Aggressive>	Set negotiation mode in phase 1 in IKE
			preShareKey <string>	Set pre shared key in phase 1 in IKE
			p1EncryAlgo <0:DES 1:3DES>	Set encryption algorithm in phase 1 in IKE
			p1AuthAlgo <0:MD5 1:SHA1>	Set authentication algorithm in phase 1 in IKE
			p1SaLifeTime <seconds>	Set sa life time in phase 1 in IKE
			p1KeyGroup <0:DH1 1:DH2>	Set key group in phase 1 in IKE
			activeProtocol <0:AH 1:ESP>	Set active protocol in phase 2 in IKE
			p2EncryAlgo <0:Null 1:DES 2:3DES>	Set encryption algorithm in phase 2 in IKE
			p2AuthAlgo <0:MD5 1:SHA1>	Set authentication algorithm in phase 2 in IKE
			p2SaLifeTime <seconds>	Set sa life time in phase 2 in IKE
			encap <0:Tunnel 1:Transport>	set encapsulation in phase 2 in IKE
			pfs <0:None 1:DH1 2:DH2>	set pfs in phase 2 in IKE
		manual	activeProtocol <0:AH 1:ESP>	Set active protocol in manual
		manual ah	encap <0:Tunnel 1:Transport>	Set encapsulation in ah in manual
			spi <decimal>	Set spi in ah in manual
			authAlgo <0:MD5 1:SHA1>	Set authentication algorithm in ah in manual
			authKey <string>	Set authentication key in ah in manual
		manual esp	encap <0:Tunnel 1:Transport>	Set encapsulation in esp in manual
			spi <decimal>	Set spi in esp in manual
			encryAlgo <0:Null 1:DES 2:3DES>	Set encryption algorithm in esp in manual
			encryKey <string>	Set encryption key in esp in manual
			authAlgo <0:MD5 1:SHA1>	Set authentication algorithm in esp in manual
			authKey < string>	Set authentication key in esp in manual

Firewall Related Command

[Home](#)

Command	Description
---------	-------------

ZyXEL Confidential

sys	Firewall			
		acl		
			disp	Display specific ACL set # rule #, or all ACLs.
		active	<yes no>	Active firewall or deactivate firewall
		clear		Clear firewall log
		cnt		
			disp	Display firewall log type and count.
			clear	Clear firewall log count.
		disp		Display firewall log
		online		Set firewall log online.
		pktdump		Dump the 64 bytes of dropped packet by firewall
		update		Update firewall
		dynamicrule		
		tcprst		
			rst	Set TCP reset sending on/off.
			rst113	Set TCP reset sending for port 113 on/off.
			display	Display TCP reset sending setting.
		icmp		
		dos		
			smtp	Set SMTP DoS defender on/off
			display	Display SMTP DoS defender setting.
			ignore	Set if firewall ignore DoS in lan/wan/dmz/wlan
		ignore		
			dos	Set if firewall ignore DoS in lan/wan/dmz/wlan
			triangle	Set if firewall ignore triangle route in lan/wan/dmz/wlan